

PTN-3219

DP26790-44:

- Trim panel to  $27\frac{1}{2}$ - $29\frac{1}{4}$ -inch x  $42\frac{1}{2}$ -inch.

9020-781 Hemlock:

- Cut two  $2\frac{1}{2}$ - $1\frac{3}{4}$ -inch x WOF Strips. Subcut two  $2\frac{1}{2}$ - $1\frac{3}{4}$ -inch x  $41\frac{1}{2}$ -inch Strips. (**Border 1**)
- Cut two  $2\frac{1}{2}$ -inch x WOF Strips. Subcut two  $2\frac{1}{2}$ -inch x 32-inch Strips. (**Border 1**)

- Add **Hemlock Border 1**. Sew Hemlock  $2\frac{1}{2}$ - $1\frac{3}{4}$ -inch x  $41\frac{1}{2}$ -inch Strips to the left side and the right side of Panel. Then, sew Hemlock  $2\frac{1}{2}$ -inch x 32-inch Strips to top and bottom of Panel.

Figure correction




Figure 1 Flying Geese construction